




# Setup Instructions


# Quick Setup

1




**NOTE:** Your computer has a preinstalled battery. Before you press the power button to turn on the computer for the first time, make sure that the AC adapter is connected to the computer.


2




# Quick Tour



- 1 Internal microphones (2)
- 2 Wireless antennas
- 3 Webcam
- 4 Webcam light
- 5 Wireless button and light
- 6 Mute button and light
- 7 Fingerprint reader\*
- 8 Right TouchPad button
- 9 Left TouchPad button
- 10 TouchPad
- 11 TouchPad on/off button and TouchPad light
- 12 Caps lock light
- 13 Power light
- 14 Power button



- 15 Security cable slot
- 16 Vent
- 17 External monitor port
- 18 USB port
- 19 Smart card reader



- 20 USB Type-C port
- 21 Dual-Mode DisplayPort
- 22 Memory Card Reader
- 23 Audio-out (headphone) and audio-in (microphone) combo jack
- 24 USB port
- 25 RJ-45 (network) jack
- 26 Docking connector
- 27 SIM slot
- 28 Power connector



- 29 Wireless light
- 30 Power light
- 31 Battery light
- 32 Drive light

\* Select products only.



**NOTE:** Computer color, features, and accessories may vary.




**NOTE:** Refer to the illustration that most closely matches your computer.



# TouchPad Features

## Turn the TouchPad off and on

Quickly double-tap the TouchPad on/off button located in the upper-left corner of the TouchPad.




## Use touch gestures




Use these common touch gestures with the TouchPad and, on select computer models, with a touch screen. For information about additional gestures, refer to the user guide included with your computer.

To locate the user guide, see the "Locate your user guides" section of this poster.

### Scroll



### Pinch/Zoom



**NOTE:** Some software programs do not support gestures.

# More Features

## Go wireless

Wireless features provide the most flexibility and convenience for staying connected to your family, friends, work, and the Internet.

To connect to a wireless network:



1. Select the network icon in the notification area.
2. Select your network from the list of available networks.
3. Enter the security key, if required.

For more information about wireless networks, see your user guides.

## Locate system information


Depending on your computer model, a service label is either affixed to the bottom of the computer or is located inside the battery bay or beneath the service door.

In Windows, briefly press the **fn+esc** key combination to display the System Information screen, which provides the product name and serial number of your computer, as well as information about the memory, processor, BIOS, and keyboard.

### Locate your user guides

For detailed information, refer to the user guides on your computer. Use one of the following methods to locate your guides and additional support tools:



- On Windows® models, select **Start**  **> All Programs > HP Help and Support > HP Documentation.**
- On Linux models, select the **HP Documents** icon on the desktop.
- On FreeDOS models, on the Boot menu, select **HP Documents.**
- Refer to the *User Guides* disc included with some models.



**NOTE:** You do not need to connect to the Internet to access HP Help and Support and the user guides.

## Feedback on this document

To help us improve this document, please send any suggestions, comments, or errors to [doc.feedback@hp.com](mailto:doc.feedback@hp.com). Include the document part number (located near the bar code) when submitting your feedback.

## Contact support

To resolve a hardware or software problem, go to <http://www.hp.com/support>. Use this site to get more information about your product, including links to discussion forums and instructions on troubleshooting. You can also find information on how to contact HP and open a support case.



## Regulatory Model Number and Simplified Declaration of Conformity

The Regulatory Model Number (RMN) for this equipment is HSTNN-133C-4 or HSTNN-133C-5 or HSTNN-141C-4 or HSTNN-141C-5. The RMN is located on the bottom of the computer.

Hereby, HP declares that this equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. To view the Declaration of Conformity for this equipment, go to [www.hp.eu/certificates](http://www.hp.eu/certificates) and search using this equipment's RMN.

## Software terms

By installing, copying, downloading, or otherwise using any software product preinstalled on this computer, you agree to be bound by the terms of the HP End User License Agreement (EULA). If you do not accept these license terms, your sole remedy is to return the entire unused product (hardware and software) within 14 days for a refund subject to the refund policy of your seller.

For any further information or to request a full refund for the price of the computer, please contact your seller.

## Limited Warranty

You can find your HP Limited Warranty located with the user guides on your product and/or on the CD or DVD provided in the box. In some countries or regions, HP may provide a printed warranty in the box. For countries or regions where the warranty is not provided in printed format, you can request a copy from <http://www.hp.com/go/orderdocuments>. For products purchased in Asia Pacific, you can write to HP at Hewlett Packard, POD, P.O. Box 200, Alexandra Post Office, Singapore 911507. Include your product name, and your name, phone number, and postal address.



**WARNING:** To reduce the risk of electric shock or damage to your equipment:

- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the computer by unplugging the power cord from the AC outlet.
- If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.

For more safety and regulatory information, and for battery disposal information, refer to the *Regulatory, Safety and Environmental Notices* provided with your user guides. To locate the user guides for your computer, refer to the "Locate your user guides" section of this poster.



**WARNING:** To reduce the risk of serious injury, read the *Safety & Comfort Guide* provided with your user guides. It describes proper workstation setup, and proper posture, health, and work habits for computer users. The *Safety & Comfort Guide* also provides important electrical and mechanical safety information. The *Safety & Comfort Guide* is also available on the Web at <http://www.hp.com/ergo>.



**WARNING:** To reduce the possibility of heat-related injuries or of overheating the computer, do not place the computer directly on your lap or obstruct the computer air vents. Use the computer only on a hard, flat surface. Do not allow another hard surface, such as an adjoining optional printer, or a soft surface, such as pillows or rugs or clothing, to block airflow. Also, do not allow the AC adapter to contact the skin or a soft surface, such as pillows or rugs or clothing, during operation. The computer and the AC adapter comply with the user-accessible surface temperature limits defined by the International Standard for Safety of Information Technology Equipment (IEC 60950-1).

## Product description

This product is a lightweight notebook computer and features a thin-panel display, TouchPad, processor, keyboard, RAM, integrated battery pack, hard drive or solid state drive, and an external AC adapter. The printed Setup Instructions identify the hardware components of your computer. Depending on your computer model, the AC adapter has a rating of 100–240 V ac, 50/60 Hz, 2.3–4.6 A.

To access the latest user guide, go to <http://www.hp.com/support>, and select your country. Select **Drivers & Downloads**, and then follow the on-screen instructions.

© Copyright 2015 HP Development Company, L.P.

Windows is a U.S. registered trademark of the Microsoft group of companies. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: August 2015

Printed in U.S.A.



830999-001